

KINETIC CLASSICGAITER BOOT FOOT PANT



Waders Size Chart

Choosing the right size is the key for optimal comfort and performance. The right fit must be snug but not too tight. Too tight fit can cause stretching of the seams and result in leakage.

The sizes are available in Standard. An average built person's starting point is the Standard size.

To give you an indication of your size, follow the measurements shown in the tables below, using the 6 measuring points being Waist, Hip, Thigh, Inseam, Outseam and Sock inside length. This will give you a fairly good idea about the size you need, but trying the waders at your local retailer is always recommended.

KINETIC WADERS SIZE CHART

Standard	40-41	42-43	44-45	44-45	46-47	46-47
Waist cm	107	116	125	131	131	141
Hip cm	109	119	129	135	135	146
Thigh cm	68.5	73.5	78.5	81.5	81.5	87
Inseam cm	88	91	94	97	97	99
Outseam cm	110.5	116.5	122.5	127.5	127.5	129.5
Boot inside length cm	25,5	26,5	28,5	30	30,5	30,5

